

## 3 Phase Half/Full Controlled Bridge Converter/Rectifier



**Product Categories:** [Electronics](#), [Engineering Equipment](#), [Power Electronics Lab](#), [Power Electronics Lab](#)

**Product Page:**

<https://www.labappara.com/product/3-phase-half-full-controlled-bridge-converter-rectifier/>

### Product Description

3 Phase Half/Full Controlled Bridge Converter/Rectifie

**Features: The board consists of following built-in parts:**

UJT relaxation oscillator and triggering pulse generator with resistance ramp control

Three numbers of pulse transformers each 1:1:1 type

Mains transformer having outputs 0-12V at 100 mA, 0-12V at 100 mA & 0-32V at 500 mA

Two SCRs connected in pulse amplifier and extender configuration and used as auxiliary SCR for triggering main SCRs underreactive load

Two SCRs and two diodes connected in half-controlled bridge configuration

Four SCRs connected in full wave bridge configuration

Resistive, Inductive and Capacitive load which can be used individually or in combinations

Mains ON/OFF switch, Fuse and Jewel light

The unit is operative on 230V  $\pm$ 10% at 50Hz A.C. Mains

Weight : 3 Kg. (Approx.)

Dimension : W 340 x H 110 x D 210