

## 6264 Ram Study Card



**Product Categories:** [Electronics](#), [Engineering Equipment](#), [Microprocessor & Micro-controller Lab](#), [Microprocessor & Micro-controller Lab](#), [Study Cards](#), [Study Cards](#)

**Product Page:** <https://www.labappara.com/product/6264-ram-study-card/>

### Product Description

#### 6264 Ram Study Card

A highly reliable machine, gold plated, socket provided to insert RAM under study.

Provision to study the Read / Write waveform. timing diagram of popular RAM like 6264, 6256 etc.

Read & Write operation can be selected by jumper

12 bit counter for address generation.

12 LED's are provided to indicate the address of the RAM.

8 Bit data can be written in to the RAM through a buffer.

Data selection by jumper pins.

8 LEDs provided to indicate the Data In or Data Out of RAM.

Circuit provision for WRITE PROTECTING the RAM.

5V Power Supply.